








Sitthöjdstabell

Azalea och Azalea Assist (inkl Minor)

						
Sitthöjd	Storlek drivhjul	Placering drivhjul	Placering drivhjul	Placering länkhjul	Placering länkhjul	Storlek länkhjul
45	24	2		1		200
45	24	2			3	175
45	24	2			2	150
45	24	2			2	140
40	22	1		3		150
40	22	1		3		140
40	16		4	3		150
40	16		4	3		140
45	16	3		1		200
45	16	3			3	175
45	16	3			2	150
45	16	3			2	140

Sitthöjdstabell

Azalea Max och Azalea Max Assist

45	24	2		1		200
40	22	1		3		140
45	16	3		1		200

Sitthöjdstabell

Azalea och Azalea Assist med Tallsats

50	24		4		2	200
50	16		5		3	200