

Victron energy

Impulse II oplader



Yes, you can.®

Impulse II oplader

Den multifunktionelle Impulse II batterioplader er velegnet til scootere og el-kørestole.

Impuls II er velegnet til 24 volt og en række forskellige batterier, såsom GEL og AGM-batterier.

Impulse II leveres med et såkaldt "XLR-stik", som er standard ladestikket for el-scootere og el-kørestole.



Indbygget Bluetooth

Impulse II Smart har indbygget Bluetooth. VictronConnect-appen gør det muligt aflæse opladeren, foretage logs og betjene laderen ved hjælp af en smartphone, tablet eller laptop.

Dette kan være ideelt til forskellige formål, som fx service og vedligeholdelse.

Impulse II	24/6 24/6 Smart	24/8 24/8 Smart	24/11 Smart	24/12 Smart
Input voltage	230 VAC (range 180-265 VAC)			
Frequency	50/60 Hz (range 45-65 Hz)			
Efficiency	95%			
Power consumption in no-load operation	0.5 W			
Charge voltage 'absorption'	28.8 V			
Charge voltage 'float'	27.6 V			
Charge voltage 'storage'	26.4 V			
Temperature compensation	-32 mV/°C			
Charge algorithm	4-stage adaptive			
Charge current	6 A	8 A	11 A	12 A
Minimum battery capacity	60 Ah	80 Ah	110 Ah	120 Ah
Back current drain	1 mA (0,7 Ah/month)			
Protection	Reverse polarity Output short circuit Over temperature			
Temperature range	-30 to +60°C (rated output current up to 30°C)			
Cooling	Natural convection			
Bluetooth communication	Smart version only			
ENCLOSURE				
Material and colour	PC-ABS, dark grey (RAL7021)			
Battery connection	Black cable with XLR connector, length 1.9 meter			
230 V AC connection	Cable of 1,9 meter with CEE 7/17 plug			
Protection category	IP44 and IP65 versions available			
Weight	1.3 kg			
Dimensions (h x w x d)	60 x 105 x 190 mm			
STANDARDS				
Safety	IEC 60601, EN 60335-1, EN 60335-2-29, EN 12184, ISO 7176-14			
Emission	EN 55014-1, EN 61000-6-3, EN 61000-3-2, ISO 7176-26			
Immunity	EN 55014-2, EN 61000-6-1, EN 61000-6-2, EN 61000-3-3			